

Yealink T44U Phone



Yealink T44U - T44W User Guide

Overview



Place a call

- Using the handset:
 - Pick up the handset.
 - Enter the number and press Send.
- Using the speakerphone:
 - With the handset on-hook, press the speaker key
 - Enter the number and press Send.
- Using the headset:
 - With the headset connected, press the headset key.
 - Enter the number and press Send.

Answer a call

- Pick up the handset, press the speaker or headset key

End a call


- Press EndCall or Hang up the handset, press the speaker or headset key

Call Hold and Resume

- To Hold: press Hold during an active call
- To Resume:
 - If there is only one call on hold, press Resume
 - If more, use the navigation keys to select the desired entry and press Resume.

Call Park

- This is what you should use all the time. This is the same as hold, but another person can pick up the parked call on another phone.



While on the call, press any of the three park keys located on the left hand side of your display (Refer to picture)

Redialing a number

- Press the Redial key to enter Placed Calls list
- Press the up and down arrows to select the desired entry.
- Press the Redial key once again or the send soft key

Unpark a call

- To unpark a call, press whichever park key is lit up for the line you want to answer (Park 1, Park 2, Park 3)

Checking voicemail



Revision #1

Created 2025-07-23 14:26:03 EDT by Corey Schneer

Updated 2025-07-23 14:33:35 EDT by Corey Schneer